

# REPORT OF 031124

1. [Introduction](#)
2. [Summary](#)
  - [Instrument Unavailability](#)
  - [Browse Visual Inspection](#)
  - [Module Stepping Results](#)
  - [Data Analysis](#)
3. [Module Stepping](#)
4. [Internal Calibration pulses](#)
  - [Daily statistics \(row 3 and 24\)](#)
  - [Cyclic statistics \(row 3 and 24\)](#)
  - [cal pulses monitoring \(all rows\)](#)
5. [Raw Data Statistics](#)
  - [raw data mean I and Q](#)
  - [raw data stdev I and Q](#)
  - [raw gain imbalance](#)
6. [Wave Doppler analysis](#)
  - [Unbiased Doppler Error](#)
  - [Absolute Doppler](#)
  - [Doppler evolution versus ANX](#)

## 1 - Introduction

This report is based on the analysis of wave mode level-1 cross spectra (ASA\_WVS\_1P) products, which are the available few hours after the acquisition, on the high rate browse (BP) products and on the Module Stepping (MS) product.

## 2 - Summary

### 2.1 - Instrument Unavailability

No unavailabilities during the reported period.

### 2.2 - Browse Visual Inspection

No anomalies observed on available browse products

### 2.3 - Data Analysis

- Stable wave internal calibration pulses gain and phase.
- Stable raw data statistics.

-Nominal Doppler behavior.

### 3 - Module Stepping Mode

The MS mode provides an internal health check on an individual module basis. The purpose of this mode is to identify any malfunctioning modules and to identify modules for which calibration offsets are to be applied. No anomalies observed on available MS products:

Polarisation	Start Time
V	20031123 185409
H	20031123 185249

#### MSM in V/V polarisation

Pre-launch Reference	DDS-B (2003-06-12) reference
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>

#### MSM in H/H polarisation

Pre-launch Reference	DDS-B (2003-06-12) reference
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/>	<input type="checkbox"/>

### 4 - Internal calibration Results

No anomalies observed.

#### 4.1 - Daily statistics

row	stat	AveP1	AveP2	AveP3
3	mean			
	stdev			

24	mean			
	stdev			



## 4.2 - Cyclic statistics

row	stat	AveP1	AveP2	AveP3
3	mean	-3.77410	-22.5546	-8.15699
	stdev	0.00611424	0.0664426	0.00320009
24	mean	-5.24803	-21.2446	-8.15699
	stdev	0.543289	0.0602883	0.00320009



## 4.3 - cal pulses monitoring (all rows)



## 5 - RAW data statistics

No anomalies observed.

### 5.1 - Input mean I/Q

channel	stat	DSS-B
MEAN I	mean	0.000322576
	stdev	1.09035e-05
MEAN Q	mean	0.000151252
	stdev	1.08872e-05



### 5.2 - Input stdev I/Q

channel	stat	DSS-B
STDEV I	mean	0.112698
	stdev	0.00154663

STDEV Q	mean	0.112948
	stdev	0.00156335



### 5.3 - Gain imbalance I/Q



## 6 - Wave Doppler Analysis

No anomalies observed Doppler evolution.  
Doppler analysis performed over the last 35 days

### 6.1 - Unbiased Doppler Error

#### Evolution of unbiased Doppler error (Real - Expected)

Ascending
Descending

### 6.2 - Absolute Doppler

#### Evolution of Absolute Doppler

Ascending
Descending


### 6.3 - Doppler evolution versus ANX

#### Evolution Doppler error versus ANX







Average P1 (row 3 & row 24)



Average P2



Average P3



No anomalies observed on available browse products


No anomalies observed.




- Stable wave internal calibration pulses gain and phase.
- Stable raw data statistics.
- Nominal Doppler behavior.

No anomalies observed Doppler evolution.  
Doppler analysis performed over the last 35 days


Doppler 'WVS' 'IS2' 'H/H'




Doppler 'WVS' 'IS2' 'V/V'



Doppler difference, estimated-predicted 'WVS' 'IS2' 'H/H' -error mean of -93.639487 Hz



Doppler difference, estimated-predicted 'WVS' 'IS2' 'V/V' -error mean of -89.022777 Hz



The MS mode provides an internal health check on an individual module basis.  
The purpose of this mode is to identify to identify any malfunctioning modules and  
to identify modules for which calibration offsets are to be applied.  
No anomalies observed on available MS products:

No anomalies observed.




















































No unavailabilities during the reported period.