

REPORT OF 040216

1. [Introduction](#)
2. [Summary](#)
 - [Instrument Unavailability](#)
 - [Browse Visual Inspection](#)
 - [Module Stepping Results](#)
 - [Data Analysis](#)
3. [Module Stepping](#)
4. [Internal Calibration pulses](#)
 - [Daily statistics \(row 3 and 24\)](#)
 - [Cyclic statistics \(row 3 and 24\)](#)
 - [cal pulses monitoring \(all rows\)](#)
5. [Raw Data Statistics](#)
 - [raw data mean I and Q](#)
 - [raw data stdev I and Q](#)
 - [raw gain imbalance](#)
6. [Wave Doppler analysis](#)
 - [Unbiased Doppler Error](#)
 - [Absolute Doppler](#)
 - [Doppler evolution versus ANX](#)

1 - Introduction

This report is based on the analysis of wave mode level-1 cross spectra (ASA_WVS_1P) products, which are the available few hours after the acquisition, on the high rate browse (BP) products and on the Module Stepping (MS) product.

2 - Summary

2.1 - Instrument Unavailability

Starting at 19h36 on 13 february 2004 repeated tile averaged temperature OOLS were reported on tile A1 until 15 february 2004 07h50. Antenna was restarted according to the predefined procedure

2.2 - Browse Visual Inspection

No anomalies observed on available browse products

2.3 - Data Analysis

-Stable wave internal calibration pulses gain and phase.

- Stable raw data statistics.
- Nominal Doppler behavior.

3 - Module Stepping Mode

The MS mode provides an internal health check on an individual module basis. The purpose of this mode is to identify any malfunctioning modules and to identify modules for which calibration offsets are to be applied. MS products are missing.

Polarisation	Start Time
V	20040214 202246
H	20040213 191227

MSM in V/V polarisation

Pre-launch Reference	DDS-B (2003-06-12) reference
⊗	⊗
⊗	⊗
⊗	⊗
⊗	⊗

MSM in H/H polarisation

Pre-launch Reference	DDS-B (2003-06-12) reference
⊗	⊗
⊗	⊗
⊗	⊗
⊗	⊗

4 - Internal calibration Results

No anomalies observed.

4.1 - Daily statistics

row	stat	AveP1	AveP2	AveP3
3	mean	-3.64809	-22.4086	-8.13224
	stdev	0.00558979	0.0743773	0.00273921

24	mean	-5.04886	-21.0495	-8.13224
	stdev	0.0119703	0.0708271	0.00273921



4.2 - Cyclic statistics

row	stat	AveP1	AveP2	AveP3
3	mean	-3.66441	-22.4435	-8.14024
	stdev	0.00701918	0.0730731	0.00314719
24	mean	-5.10421	-21.0966	-8.14024
	stdev	0.0151022	0.0681923	0.00314719



4.3 - cal pulses monitoring (all rows)



5 - RAW data statistics

No anomalies observed.

5.1 - Input mean I/Q

channel	stat	DSS-B
MEAN I	mean	0.000438163
	stdev	2.78143e-07
MEAN Q	mean	0.000379254
	stdev	3.24034e-07



5.2 - Input stdev I/Q

channel	stat	DSS-B
STDEV I	mean	0.120370
	stdev	0.00134973

STDEV Q	mean	0.120603
	stdev	0.00136471



5.3 - Gain imbalance I/Q



6 - Wave Doppler Analysis

Preliminary report. The data is not yet controlled

6.1 - Unbiased Doppler Error

Evolution of unbiased Doppler error (Real - Expected)
Ascending
Descending


6.2 - Absolute Doppler

Evolution of Absolute Doppler
Ascending
Descending


6.3 - Doppler evolution versus ANX

Evolution Doppler error versus ANX



Average P1 (row 3 & row 24)




Average P2




Average P3




Average P1 (row 3 & row 24)



Average P2











Average P3




No anomalies observed on available browse products

No anomalies observed.






- Stable wave internal calibration pulses gain and phase.
- Stable raw data statistics.
- Nominal Doppler behavior.

Doppler 'WVS' 'IS2' 'H/H'




Doppler 'WVS' 'IS2' 'V/V'






Doppler difference, estimated-predicted 'WVS' 'IS2' 'H/H' -error mean of -32.376902 Hz







Doppler difference, estimated-predicted 'WVS' 'IS2' 'V/V' -error mean of -30.776972 Hz






The MS mode provides an internal health check on an individual module basis.
The purpose of this mode is to identify to identify any malfunctioning modules and
to identify modules foe which calibration offsets are to be applied.
MS products are missing.

No anomalies observed.







Starting at 19h36 on 13 february 2004 repeated tile averaged temperature OOLS were reported on tile A1 until 15 february 2004 07h50.
Antenna was restarted according to the predefined procedure