

PRELIMINARY REPORT OF 040229

ATTENTION: This report is automatically generated no comments are provided on data analysis

1. [Introduction](#)
2. [Summary](#)
 - [Instrument Unavailability](#)
 - [Browse Visual Inspection](#)
 - [Module Stepping Results](#)
 - [Data Analysis](#)
3. [Module Stepping](#)
4. [Internal Calibration pulses](#)
 - [Daily statistics \(row 3 and 24\)](#)
 - [Cyclic statistics \(row 3 and 24\)](#)
 - [cal pulses monitoring \(all rows\)](#)
5. [Raw Data Statistics](#)
 - [raw data mean I and Q](#)
 - [raw data stdev I and Q](#)
 - [raw gain imbalance](#)
6. [Wave Doppler analysis](#)
 - [Doppler evolution versus ANX](#)

1 - Introduction

This report is based on the analysis of wave mode level-1 cross spectra (ASA_WVS_1P) products, which are the available few hours after the acquisition, on the high rate browse (BP) products and on the Module Stepping (MS) product.

2 - Summary

2.1 - Instrument Unavailability

No unavailabilities during the reported period.

2.2 - Browse Visual Inspection

2.3 - Data Analysis

-Stable wave internal calibration pulses gain and phase.

- Stable raw data statistics.
- Nominal Doppler behavior.

3 - Module Stepping Mode

The MS mode provides an internal health check on an individual module basis. The purpose of this mode is to identify any malfunctioning modules and to identify modules for which calibration offsets are to be applied.

No anomalies observed on available MS products:

| Polarisation | Start Time |
|--------------|-----------------|
| V | 20040227 201408 |
| H | 20040227 201248 |

MSM in V/V polarisation

| Pre-launch Reference | DDS-B (2003-06-12) reference |
|----------------------|------------------------------|
| ☒ | ☒ |
| ☒ | ☒ |
| ☒ | ☒ |
| ☒ | ☒ |

MSM in H/H polarisation

| Pre-launch Reference | DDS-B (2003-06-12) reference |
|----------------------|------------------------------|
| ☒ | ☒ |
| ☒ | ☒ |
| ☒ | ☒ |
| ☒ | ☒ |

4 - Internal calibration Results

No anomalies observed.

4.1 - Daily statistics

| row | stat | AveP1 | AveP2 | AveP3 |
|-----|-------|------------|-----------|------------|
| 3 | mean | -3.62389 | -22.3913 | -8.13202 |
| | stdev | 0.00569684 | 0.0707024 | 0.00261701 |

| | | | | |
|----|-------|-----------|-----------|------------|
| 24 | mean | -5.08075 | -21.0564 | -8.13202 |
| | stdev | 0.0139481 | 0.0723941 | 0.00261701 |



4.2 - Cyclic statistics

| row | stat | AveP1 | AveP2 | AveP3 |
|-----|-------|------------|-----------|------------|
| 3 | mean | -3.64325 | -22.4019 | -8.13294 |
| | stdev | 0.00653432 | 0.0774629 | 0.00304574 |
| 24 | mean | -5.10619 | -21.0720 | -8.13294 |
| | stdev | 0.0145928 | 0.0744860 | 0.00304574 |



4.3 - cal pulses monitoring (all rows)



5 - RAW data statistics

No anomalies observed.

5.1 - Input mean I/Q

| channel | stat | DSS-B |
|---------|-------|-------------|
| MEAN I | mean | 0.000445939 |
| | stdev | 2.63508e-07 |
| MEAN Q | mean | 0.000420296 |
| | stdev | 3.03246e-07 |



5.2 - Input stdev I/Q

| channel | stat | DSS-B |
|---------|-------|------------|
| STDEV I | mean | 0.122464 |
| | stdev | 0.00126155 |

| | | |
|---------|-------|------------|
| STDEV Q | mean | 0.122689 |
| | stdev | 0.00127518 |



5.3 - Gain imbalance I/Q



6 - Wave Doppler Analysis


Preliminary report. The data is not yet controlled

6.1 - Doppler evolution versus ANX


Evolution Doppler error versus ANX




Average P1 (row 3 & row 24)




Average P2




Average P3




Average P1 (row 3 & row 24)



28-Feb
Average P2




28-Feb
Average P3




28-Feb

No anomalies observed.






- Stable wave internal calibration pulses gain and phase.
- Stable raw data statistics.
- Nominal Doppler behavior.

Doppler 'WVS' 'IS2' 'H/H'




Doppler 'WVS' 'IS2' 'V/V'






Doppler difference, estimated-predicted 'WVS' 'IS2' 'H/H' -error mean of -31.010208 Hz







Doppler difference, estimated-predicted 'WVS' 'IS2' 'V/V' -error mean of -28.729499 Hz






The MS mode provides an internal health check on an individual module basis.
The purpose of this mode is to identify to identify any malfunctioning modules and
to identify modules for which calibration offsets are to be applied.
No anomalies observed on available MS products:

No anomalies observed.







No unavailabilities during the reported period.