

# REPORT OF 040322

last update on Mon Mar 22 15:39:51 GMT 2004

1. [Introduction](#)
2. [Summary](#)
  - [Instrument Unavailability](#)
  - [Browse Visual Inspection](#)
  - [Module Stepping Results](#)
  - [Data Analysis](#)
3. [Module Stepping](#)
4. [Internal Calibration pulses](#)
  - [Daily statistics](#)
  - [Cyclic statistics](#)
  - [cal pulses monitoring \(all rows\)](#)
5. [Raw Data Statistics](#)
  - [raw data mean I and Q](#)
  - [raw data stdev I and Q](#)
  - [raw gain imbalance](#)
6. [Wave Doppler analysis](#)
  - [Unbiased Doppler Error](#)
  - [Absolute Doppler](#)
  - [Doppler evolution versus ANX](#)

## 1 - Introduction

This report is based on the analysis of wave mode level-1 cross spectra (ASA\_WVS\_1P) products, which are the available few hours after the acquisition, on the high rate browse (BP) products and on the Module Stepping (MS) product.

## 2 - Summary

### 2.1 - Instrument Unavailability

No unavailabilities during the reported period.

### 2.2 - Browse Visual Inspection

No anomalies observed on available browse products

### 2.3 - Data Analysis

- Stable wave internal calibration pulses gain and phase.
- Stable raw data statistics.
- Nominal Doppler behavior.

### 3 - Module Stepping Mode

The MS mode provides an internal health check on an individual module basis. The purpose of this mode is to identify any malfunctioning modules and to identify modules for which calibration offsets are to be applied.

No anomalies observed on available MS products:

Polarisation	Start Time
V	20040321 195112
H	20040321 194952

#### MSM in V/V polarisation

Pre-launch Reference	DDS-B (2003-06-12) reference
⊗	⊗
⊗	⊗
⊗	⊗
⊗	⊗

#### MSM in H/H polarisation

Pre-launch Reference	DDS-B (2003-06-12) reference
⊗	⊗
⊗	⊗
⊗	⊗
⊗	⊗

### 4 - Internal calibration Results

No anomalies observed.

#### 4.1 - Daily statistics

⊗

## 4.2 - Cyclic statistics



### P1 Cyclic statistics

row	pulse	mean (dB)	stdev (dB)	slope(dB/cycle)
3	P1	-3.611399	0.006004	0.050776
7	P1	-3.318880	0.009318	0.044652
11	P1	-4.795664	0.262242	0.602033
15	P1	-5.009750	0.034003	0.026612
19	P1	-3.347657	0.072609	-0.049074
22	P1	-4.545448	0.070438	-0.035229
24	P1	-5.102586	0.091062	0.008194
28	P1	-4.578181	0.075963	-0.072937

### P2 Cyclic statistics

row	pulse	mean (dB)	stdev (dB)	slope(dB/cycle)
3	P2	-22.381872	0.081853	-0.026766
7	P2	-22.896996	0.126749	-0.025911
11	P2	-16.024626	0.158528	0.048789
15	P2	-7.176844	0.090414	0.015368
19	P2	-9.482118	0.167757	-0.004449
22	P2	-17.677443	0.104544	0.043239
24	P2	-21.035240	0.113106	-0.034929
28	P2	-16.595827	0.087259	-0.011145

### P3 Cyclic statistics

row	pulse	mean (dB)	stdev (dB)	slope(dB/cycle)
3	P3	-8.127871	0.003002	0.006923
7	P3	-8.127867	0.003003	0.006917
11	P3	-8.127868	0.003003	0.006907
15	P3	-8.127865	0.003003	0.006906
19	P3	-8.127868	0.003003	0.006902
22	P3	-8.127872	0.003003	0.006901
24	P3	-8.127876	0.003003	0.006923

### 4.3 - cal pulses monitoring (all rows)



## 5 - RAW data statistics

No anomalies observed.

### 5.1 - Input mean I/Q

channel	stat	DSS-B
MEAN I	mean	0.000471015
	stdev	2.35590e-07
MEAN Q	mean	0.000491247
	stdev	2.60472e-07



### 5.2 - Input stdev I/Q

channel	stat	DSS-B
STDEV I	mean	0.127528
	stdev	0.00113167
STDEV Q	mean	0.127764
	stdev	0.00114458



### 5.3 - Gain imbalance I/Q



## 6 - Doppler Analysis

### 6.1 - Unbiased Doppler Error

<b>Evolution of unbiased Doppler error (Real - Expected)</b>
--

Ascending
-----------

Descending
------------

### 6.2 - Absolute Doppler

<b>Evolution of Absolute Doppler</b>
--------------------------------------

Ascending
-----------

Descending
------------




### 6.3 - Doppler evolution versus ANX

<b>Evolution Doppler error versus ANX</b>
---


⊗
---

<b>Evolution Doppler error versus ANX</b>
---

⊗
---











rows: 3 7 11 15 19 22 24 28



No anomalies observed on available browse products




No anomalies observed.




- Stable wave internal calibration pulses gain and phase.
- Stable raw data statistics.
- Nominal Doppler behavior.







Doppler 'WVS' 'IS2' 'H/H'



Doppler 'WVS' 'ISZ' 'V/V'











Doppler difference, estimated-predicted 'WVS' 'IS2' 'H/H' -error mean of -31.193589 Hz



Doppler difference, estimated-predicted 'WVS' 'IS2' 'V/V' -error mean of -28.851988 Hz



-100Hz +100Hz

The MS mode provides an internal health check on an individual module basis.  
The purpose of this mode is to identify to identify any malfunctioning modules and  
to identify modules for which calibration offsets are to be applied.  
No anomalies observed on available MS products:

No anomalies observed.



















































No unavailabilities during the reported period.